
KEYGRABBER PICO QUICK START



Important tips:

- Works only with external USB keyboards, does not work with laptop keyboards
- To access data, press and hold password keys KBS together on external keyboard
- Be sure to obey keystroke recording laws and regulations in your country!



Press and hold the keys K B S together for flash drive mode




This is recorded text stored in file LOG.TXT [Ent]

Special keys and time-stamps are marked with brackets like this [Del][F1][Ent]

Recorded data is stored in file

LOG.TXT

To configure the device edit file **CONFIG.TXT** in the flash drive main folder



Memorize your password in case you change it. Otherwise access to the device will be impossible!

Password = ABC (must be 3 keys, please memorize!)

LogSpecialKeys = None / Medium / Full

DisableLogging = Yes / No

DisableLayout = Yes / No

KEYBOARD COMPATIBILITY

- ✓ Standard USB keyboards
- ✓ Keyboards with USB hubs
- ✓ Wireless keyboards (dongle)
- ✓ Keyboard + mouse combos X Some gaming
- ✓ Most Apple keyboards

- X Apple A1243
- **X** Bluetooth keyboards
- X Some gaming keyboards


To enable a national keyboard layout place a selected **LAYOUT.USB** file in the flash drive main folder

Text logged on German keyboard without layout

Kezlogger)PS-2 / USB=

Text logged with German layout applied

Keylogger (PS/2 & USB)





More information is available in the User Guide on the flash drive